

Legrand Nuvo URC Module

V1.7 rev20160804



Overview

This document details how to integrate a Legrand Nuvo Player into URC systems. This module supports user interfaces on the following URC products: TKP-7000, TKP-5500, TKP-2000, TRC-1080, TRC-1280, TRC-820, URC Mobile Phone (iOS/Android), and URC Mobile Tablet (iOS/Android).

Ensure you have setup and can control your Nuvo player with the Nuvo Application before integrating into the control system. Each player is assigned a unique network address and will need to be entered in the network setup section of the module.

Installation

- Import the URC module into Accelerator. Restart Accelerator before continuing.
- Add the module to your project (**Accelerator STEP 4**)
- Identify IP address and Port 4747 (**Accelerator STEP 6**)
 - URC requires every IP module to have an IP Address. Enter the NuVo players IP address and Port number 4747 into the appropriate network setup fields.
- Accelerate menus (**Accelerator STEP 10**)



- Specify whether the Nuvo Player will be controlling the volume by entering "HasVolumeControl=false;" or "HasVolumeControl=true;" in the System Parameter Information. (**Accelerator STEP 11**)
- Download and Test!

Tips

- Program Button RED controls like button
- Program Button BLUE controls shuffle button
- Program Button YELLOW controls repeat button
- Program Button GREEN controls dislike button
- Guide button controls group volume button
- Channel up button controls paging up the list
- Channel down button controls paging down the list (hold to ramp)
- Up button controls moving up one item in the list (hold to ramp)
- Down button controls moving down one item in the list (hold to ramp)
- Select button and Right button controls selecting currently highlighted item
- Left button controls going back to the previous list
- Volume up/down button controls the volume level (hold to ramp)
- Mute button controls the mute state
- Page left/right buttons control cycling through the types of lists